



Daikin One Lite Connected Thermostat Wiring Diagrams



Disclaimer

This material provides technical information that is to only be used by appropriately trained and certified HVAC-R installers and technicians who have agreed to the terms and conditions available here at <https://www.daikincity.com/DaikinCityB2BTermsOfUse.html>. If you have not agreed to these terms and conditions, you may not use or view this material, and you assume responsibility for any injury or property, system or equipment damage which may result. If you have agreed to these terms, you also agree, by viewing or using this material, that this material, by its nature, cannot include a discussion of everything necessary to effect a proper installation or repair of HVAC-R equipment, nor can it address every possible scenario or environment a technician or installer may encounter. Accordingly, this material should not be considered as recommendations for best practices and will not be considered installation or repair instructions to the extent of any conflict with Daikin- or Goodman-issued manuals and specifications, or industry standards and regulations. Each installer or technician remains fully responsible for ensuring proper installation or repair of the HVAC-R equipment being worked on, and you remain fully responsible for any injury or property, system or equipment damage which may result from your installation. ©2023 Daikin Comfort Technologies North America, Inc., all rights reserved; recording, copying, or distribution of this material is prohibited without express written permission from Daikin.



Indoor units that have S21 Interface

Indoor units that do not have S21 Interface



Notes: the Daikin One Lite is not compatible with:
handheld IR remote controller – BRC944 – KRP928


Indoor Unit Models (require interface adaptor)	Required Interface Adaptor
FTXM09-24VVJU, FTXM9-24WVJU9	KER087A41
FTX09NMVJU(A), FTX12NMVJU(A), FTX09WMVJU9, FTX12WMVJU9	KRP067A41E
FTX15NMVJU(A), FTX15WMVJU9	KRP980B2E



- Maximum wire distance between the Daikin *One* Lite and the translation adaptor should not exceed **125 feet using four conductor 18-gauge field supplied wire.**
- Seal the hole made for routing the wiring to the thermostat's terminal subbase.
- **Check for proper voltage before and after wiring is installed.**
 - 0.6 - 0.9VDC between Data 1 and 2
 - 24VAC between R and C
 - Line voltage 230VAC

Note: If wired incorrectly, you will receive an error.

- If power wires are reversed the PWR LED will flash green.



Aux to Aux C is a 24V AC Dry contact.

- ① Data Line 1
- ② Data Line 2
- Ⓒ 24 volt common
- Ⓓ 24 volt power



Translation Adaptor Detail

